

PC Card

平成12年6月末現在

機種名	FastEther PCC-TX
NEC PC98-NXシリーズ	
VersaPro NX	
VA20C/BS	98
VA23C/WD	98
VA23D/TX	98, 95
VA26D/WX	98
VA30D/AX	98
VA30D/TX	98
VA30H/WS	98
VA33D/WX	98
VA36D/TX	98
VA45J/WX	98
VA50J/WT	2K
VA65J/AF	98
VP23C/WX	95, NT
VP26C/WX	NT
LaVie NX	
LA500J/15D	98
LB20/40	98
LB26C/50	98
LB30C/7	98
LB40H/22D	98
LB400J/12	98
LT23/34	98
LT23D/54	98
LT30D/54	98
LT36D/6	98
LS46H/2	98
LV16C/WS	95
LW20/4	98
LW23D/53	98
LW26/3	95
LW30H/6	98
LW30H/7	98
LW33H/7	98
LW333D/7	98
LW366D/7	98
LW40H/14	98
LW40H/84	98
LW400D/84DA	98
LW450J/14CV	98
LW500J/24	98
Aile NX	
AL20C/TS	98, 95, NT
mobio NX	
MB12C/UD	98
MB20C/UV	98
VALUESTAR NX	
VC550J/1FD1	98
VF26D/6GC	98
VF26D/6GD	98
VF26D/6YC	98
VF26D/6YD	98
VF43H/8	98
NEC PC9821シリーズ	
PC-9821Ls150/S14	95
PC-9821Na13/H10	95
PC-9821Nr13/S14N	NT
PC-9821Nr15/S10	95
PC-9821Nr15/S14F	95
PC-9821Nr166/X30F	95, NT
PC-9821Nw150/S20C	98, 95, NT
akia	
Tornado	
623X	98
T509	95
CASIO	
CASSIOPEA FIVA	
MPC-101M32	98
COMPAQ	
ARMADA	
1700	98
3500	98, 95
4131T	NT
4220T	95
7730MT	95
7800 Pro	NT
PRESARIO	
1246	98
1636	98
1919	98
1920	98
1928	98
日本DEC	
Digital HiNote / Ultra / Ultra	
CS450	95
LTS5133	98
VP575	95

機種名	FastEther PCC-TX
富士通	
FMV-BIBLO / FMV-BIBLO LIFEBOOK	
FMV-475NL/S	95
FMV-5133NP/W	98
FMV-5200NA8/W	95, NT
FMV-5233MC2/W	98
FMV-6233NA2/L	NT
FMV-6266MF3/W	98
FMV-6333MF4/W	98
MC 23	98
MC 30	98
MC/30	98
MF 26	98
MF/33	98
MF2/400X	98
NC 20	98, 95
NC 23	98
NE 20D	98
NE 23X	98
NE 23X	98
NE 26X	98
NE/36L	98
NR 30L	98
NR/33X	98
NS 26X	98
NU 23	95
NU 23	98
FMV-DESKPOWER	
C2/465	98
C2/46L	98
C3/557	98
K3/50c	98
M3/557	98
FMV-DESKPOWER Pliche	
model220	98
IBM	
ThinkPad	
235 (2607-10J)	98
240 (2609-21J)	98
240 (2609-25J)	98
240 (2609-31J)	98
380ED (2635-5YJ)	95, NT
380ED (2635-6YJ)	95, NT
380ED (2635-7YJ)	95, NT
380XD (2635-8AJ)	95, NT
380XD (2635-9AJ)	95, NT
380XD (2635-AAJ)	95, NT
380XD (2635-FAJ)	95, NT
380Z (2635-HYJ)	98, 95
390 (2626-5AJ)	98
530CS (2605-1FC)	95
530CS (2605-1FD)	95
530CS (2605-1FP)	95
530CS (2605-7FD)	95
530CS (2605-7FE)	95
530CS (2605-7FQ)	95
530CS (2605-7FV)	95
530CS (2605-DFK)	95
530CS (2605-DFV)	95
535 (2606-MF9)	95
535X (2606-70J)	NT
560X (2640-70J)	95, NT
560Z (2640-9YJ)	98
560Z (2640-B0J)	98
570 (2644-AA7)	98
570E (2644-6A7)	98, 2K
600 (2645-53J)	98
600 (2645-5FJ)	98, 2K
600E (2645-55J)	98, NT
765D (9546-J9H)	98
770ED (9549-5AJ)	95
ThinkPad i Series	
1424 (2621-42)	98
1459 (2611-459)	98
日立	
FLORA	
220	98
220CX	98
FLORA Prius note	
20J (202T23J)	98
20J (202T26J)	98
210 (2109T16G)	98
210 (210T13E)	98
220K (2204T26K)	98
220M	98
230 (230T13E)	95
230 (230T16F)	95
250 (250T15E)	95
270 (270T16E)	98
270 (270T20E)	98
270 (270T23H)	98
270 (270T23H)	98
FLORA Prius DECK	
610M	98

機種名	FastEther PCC-TX
SONY	
VAIO パイオノートXR	
PCG-XR1G	98
PCG-XR7	98
PCG-XR7S	98
PCG-XR9G	98
PCG-XR9S	98
VAIO パイオノート	
PCG-715	95
PCG-733	95
PCG-737/A4G	98
PCG-767	98
PCG-861/BP	98
PCG-862	98
PCG-864	98
PCG-868	98
PCG-881/BP	98
PCG-888	98
PCG-F16/BP	98
PCG-F23/BP	98
PCG-F37/BP	98
PCG-F50/BP	98
PCG-F57/BP	98
PCG-F59DK	2K
VAIO パイオノート505	
PCG-505EX	95
PCG-505X	95
PCG-505RS	98
PCG-505RX	98
PCG-505S	98
PCG-505SX	98
PCG-505V/ABX	98
PCG-N505AS	98
PCG-N505E/BP	98
PCG-N505ES	98
PCG-Z505D	98
VAIO パイオC1	
PCG-C1	98
PCG-C1R	98
PCG-C1S	98
PCG-C1XF	98
VAIO パイオRX / パイオR	
PCV-R70	98
PCV-R71	98
VAIO パイオMX	
PCV-MX1	98
VAIO パイオL	
PCV-L320/BP	98
PCV-L330A/BP	98
PCV-L700/BP	98
PCV-L710/BP	98
DELL	
Latitude	
CPt V400ST	98
XPI 150ST	95
Inspiron	
3200 D266XT	98, 95
3700 R500GT	98
EPSON DIRECT	
Endeavor	
NT-800	98
Gateway	
Solo	
2500LS	98
3100XL	98
i COM	
COMPCHAMP	
NC2402	98
Panasonic	
Let's note	
AL-N2T516J5	95
AL-N2T520J5	95
AL-N3T516J5	98
AL-N3T520J5	98
AL-N4T512J5	95
CF-A1R	98
CF-A44EJ8	98
CF-A44J8	98
CF-C33EJ8C	98
CF-C33EJ8K	98
CF-C33J8C	98
CF-C33J8K	98
CF-M1V	98
CF-M32J8	98
CF-S21J5	98
CF-S21J8	98
CF-S51EJ8	98
CF-S51EXJ8	98
Willi PC	
CE-F1	98

機種名	FastEther PCC-TX
SHARP	
Mebius	
MN-450-H23	98
MN-7350	95
PC-DJ50M	98
PC-FJ10	98
PC-FJ100R	98
PC-FJ120M	98
PC-PJ1	95
PC-PJ1-98	98
PC-PJ1-M2	98
PC-PJ1-M3	98
PC-PJ2	98
PC-PJ2-X4	98
PC-PN200	98
SOTEC	
e-note	
640H	98
645H	98
WinBook	
Eagle 266MTX	98
Eagle/X 300CTX	98
Bird/V 166MT	98
Quattro/R 133MT	98
Quattro/V 166MX	98
Quattro/X 300TX	98
東芝	
PX100	
DynaBook	
2100	98
2650	98
4050X	98
DynaBook Satellite	
300	NT
310	95
315	95
320	98
325	98
2510	95
2520	98, 95, NT
2550S	98
2550X	98
4000X	98
4010X	98
4030X	98
4060X	2K, NT
DynaBook Satellite Pro	
480	98, 95, NT
490X	98, 95
DynaBook SS	
3020	98
3300	98
3330	98
3330V	98, 2K
3380V	98, 2K
3410	98
7020X	98, 2K, NT
PORTEGE 3000	98
PORTEGE 6000	98
PORTEGE 7000	98
DynaBook TECRA	
720	98
750	98
780DVD	95
8000	98
Dynatop	
6000	98
Libretto	
20	95
30	95
50	95
60	95
70	95
100	95
ff 1100V	98
SS 1000	98, 95
SS 1010	98
三菱電機	
apricot NOTE AL	
5200M-21TX	95
AMITY CN	
M3031-L47P1	98
Pedion	
Model111	98
SANYO	
WinKeyG1	
MBC-G1F	98